

GARAGE DOOR RADIO CONTROL

PROGRAMMING INSTRUCTIONS

FOR MODEL MT2-1000

Remove the back cover from the transmitter and the receivers for access to the code switches. Inside is a 10-bits dip switch exposed on the circuit board. Use a pencil or ball-point pen to set the 10-bits dip switch of your choice. But, note that bit numbered 8 and 10 are not operational on the transmitter.

TRANSMITTER :

Determine the bits numbered 1 - 7, 9 to ON/OFF position. For example, set bits numbered 1, 4, 9 to ON, numbered 2, 3, 5, 6, 7 to OFF.

	1	2	3	4	5	6	7	8	9	10
ON	■	□	□	■	□	□	□	□	■	□
↑	□	■	■	□	■	■	■	□	□	□

ASSOCIATED RECEIVERS :

There, are 2 coded receivers controllable by this 2-channel transmitter. Set the bits as below:

First receiver : Set the bit numbered 8 to ON and numbered 10 to OFF and others bits to the same ON/OFF position as the corresponding bits in the transmitter.

For example :

	1	2	3	4	5	6	7	8	9	10
ON	■	□	□	■	□	□	□	■	■	□
↑	□	■	■	□	■	■	■	□	□	■

Second receiver : Set the bit numbered 8 & 10 to ON, and others bits to the same ON/OFF position as the corresponding bits in the transmitter.

Be sure all are set to the definite code, since a different setting of just one dip switch will prevent operation.

***HOW TO ORDER
REPAIR PARTS***

DEVANCO CANADA

19192 HAY ROAD, UNIT Q
SUMMERSTOWN, ON K0C 2E0

TOLL FREE: 855-931-3334

www.devancocanada.com

**WHEN ORDERING REPAIR PARTS
PLEASE SUPPLY THE
FOLLOWING INFORMATION:**

- ✓ PART NUMBER**
- ✓ DESCRIPTION**
- ✓ MODEL NUMBER**