

P-8833TC-OCS & P-733T

P-8833TC-OCS



P-733T



Open, Close & Stop Transmitter to Control 3 Doors. Match dipswitches 1, 2, 3, 4, 5, 7 & 8 on both transmitter and receiver. Set the 6th dipswitch in open/close/stop receivers

accordingly.

Receiver	Slide Switch	6th Dipswitch Receiver
Door 1	A	"+"
Door 2	В	"O"
Door 3	С	<u>‹‹</u> ››

[&]quot;Changes or modifications not expressively approved by the party responsible for compliance could void the user's authority to operate the equipment"