

3-BUTTON TRANSMITTER MODEL LX3B (P/N 7357-360)



DURING PROGRAMMING THE GARAGE DOOR MAY OPERATE. KEEP PEOPLE AND OBJECTS CLEAR OF THE MOVING DOOR TO PREVENT DOOR DAMAGE OR POSSIBLE PERSONAL INJURY.

NOTE: Any of the three transmitter buttons can be programmed to activate the door. In multi-door installations, each button can be programmed to activate a separate door.


NOTE: Programming failure can occur if the wall station or transmitter is too close to the opener during the programming sequence. There must be a minimum of 6 feet between the wall station/transmitter and the opener.

NOTE: The opener can be activated by up to 8 remote transmitters. If a 9th remote is programmed, the first remote programmed will be lost from memory and will not operate the opener.

NOTE: Do not press any button on the wall station or transmitter until instructed.

Transmitter Programming:

1. Press and hold the LEARN button located on the garage door opener until the Right LED lights, then release the LEARN button. The LED will remain lit, indicating activation of the learn mode.



2. Press one of the buttons on the transmitter you wish to use to operate the door. The Right LED on the garage door opener will turn on and off three times indicating a successful learn.

3. Press the same button on the transmitter once more to confirm operation. The opener will turn on and move the door. At this point you will be able to activate the opener.

Battery Replacement:

Failure of opener to respond to transmitter, may be due to weak or dead battery. To change the battery, insert a coin in the coin slot and twist to access the battery compartment.

The transmitter uses (1) CR2016 battery. Install fresh battery with the positive (+) of the battery facing up. Snap top case half onto bottom case half. Dispose of replaced battery properly.



FIRE AND BURN HAZARD. DO NOT RECHARGE, DISASSEMBLE, HEAT, OR INCINERATE. KEEP BATTERY OUT OF THE REACH OF CHILDREN. INSTALL BATTERY CORRECTLY. DISPOSE OF USED BATTERIES PROMPTLY.

**For more information, please visit www.devancocanada.com
or call toll free at 855-931-3334**

***HOW TO ORDER
REPAIR PARTS***

DEVANCO CANADA

19192 HAY ROAD, UNIT Q
SUMMERSTOWN, ON K0C 2E0

TOLL FREE: 855-931-3334

www.devancocanada.com

**WHEN ORDERING REPAIR PARTS
PLEASE SUPPLY THE
FOLLOWING INFORMATION:**

- ✓ PART NUMBER
- ✓ DESCRIPTION
- ✓ MODEL NUMBER