


GARAGE DOOR RADIO CONTROL

CODING INSTRUCTION FOR MODEL MCT-4

Remove the back cover from the transmitter and the receiver for access to the code switches. Inside is a 8-bits dip switch exposed on the circuit board. Use a pencil or ball-point pen to set the 8-bits dip switch of your choice. But, note that bits numbered 1 and 2 are not operational on the transmitter.

TRANSMITTER :

Determine the bits numbered 3 - 8 to ON/OFF position, For example, set bits numbered 3, 5, 6, 8, to ON, numbered 4, 7 to OFF.




ASSOCIATED RECEIVERS :

There are 4 coded receivers controllable by this 4-channel transmitter.

Set the bits as below :

- a) First, follow same bits numbered 3 - 8 to ON/OFF as the corresponding bits in the transmitter as above example.



- b) Then, set the bits numbered 1 and 2 to fixed position as follows, for matching the transmitter switch button accordingly.

Transmitter button switch	Receiver	Dip switch								
		1	2	3	4	5	6	7	8	
A	1st	ON	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
		↑	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
B	2nd	ON	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
		↑	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
C	3rd	ON	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
		↑	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
D	4th	ON	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
		↑	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>

Be sure all are set to the definite code, since a different setting of just one dip switch will prevent operation.

***HOW TO ORDER
REPAIR PARTS***

DEVANCO CANADA

19192 HAY ROAD, UNIT Q
SUMMERSTOWN, ON K0C 2E0

TOLL FREE: 855-931-3334

www.devancocanada.com

**WHEN ORDERING REPAIR PARTS
PLEASE SUPPLY THE
FOLLOWING INFORMATION:**

- ✓ PART NUMBER
- ✓ DESCRIPTION
- ✓ MODEL NUMBER